CIMARRON SPORTS

SERIOUS TOOLS FOR TRAINING SERIOUS ATHLETES

Combo Pitching Machine
USER MANUAL

TABLE OF CONTENTS

Thank you for purchasing the **Cimrnarron Combo-Pitch Pitching Machine**. The **Cimarron Combo-Pitch Pitching Machine** is a high performance pitching machine designed to give you years of enjoyment.

This booklet provides you with:

1. Assembly Instructions…….Page 3
2. Specifications/Features……..Page 4
3. Operating Instructions ……Page 5
4. Safety Instructions……...Page 8
5. Maintenance Instructions……Page 10
6. Warranty Information…….. Page 11

Please read this booklet and pay attention to each section. It is important that the pitching machine is assembled correctly.

It is also important that you fully understand the operating instructions and maintenance of the machine before you operate it.

The warranty provides you with the confidence that you have purchased a quality pitching machine and that the manufacturer stands behind the product and will provide service.

If you have any problems with assembling this pitching machine or its initial use, please call Cimarron Sports Service Department at 888-816-6517.

IMPORTANT!!

If you use an extension cord, you must comply with the 'wire GAUGE to cord LENGTH' as noted on page 9 in this manual. A normal extension cord is **"18 gauge"** and is not acceptable. If this is not complied with, the warranty will be voided.

Cimarron Sports
PO Box 692045
Tulsa, OK 74169
(918) 301-3609
888-816-6517

Removing your Combo-Pitch Pitching Machine from the package

Carefully lift the machine from the box. Please be certain to maintain careful balance and use proper lifting techniques as the machine unit alone weighs 45 lbs. *Lift by the metal parts ONLY!*

Set the machine on the floor in the same position as it arrived in the box. *Do not set the machine down with the control panel or with the speed adjustment knob touching the floor.*

Verify all pieces *(See Figure 1)*. You should have the following pieces in each box:

BOX 1

A. 1 pitching machine unit

B. 1 softball attachment

C. 3 leg sets

D. 1 wrench



ASSEMBLY INSTRUCTIONS

1. **Assemble the legs (Baseball)**
   a. Attach the top section of the leg to the bottom section. Repeat for each leg.

   b. Loosen screws on tripod base to allow room for tripod leg to be inserted all the way.

   c. Insert the tripod leg all the way, then tighten the screw to hold it in place.

   d. Repeat steps for remaining legs. *(See Figure 2).*



Figure 2

Congratulations! Your new **Cimarron Combo-Pitch Pitching Machine** is now ready to go!

SPECIFICATIONS/FEATURES

- Pitches up to 60mph*
- Adjustable speed control
- Designed for dimpled balls **
- Can be used for baseball or softball
- Runs on 110 AC
- Adjustable swivel for precise aiming
- Adjustable tilt
- Baseball and softball feed chute included
- Protective wheel cover
- Steel grill hand guard
- Solid state electronic control
- Molded polyurethane wheel designed for accurate pitches
- Steel construction
- Weighs 66 lbs. assembled

*Softballs will not pitch as fast as baseballs. To achieve maximum speed, set the speed control to 8.5 and use the harder dimpled balls. Softer dimpled balls will not pitch as fast.

** The **Cimarron Combo-Pitch Pitching Machine** is designed to use dimpled baseballs and dimpled softballs only. Using leather or synthetic leather balls with the **Cimarron Combo-Pitch Pitching Machine** voids the warranty.



OPERATING INSTRUCTIONS

Basic Pitching Operation:

Place the machine on the pitcher's mound or in an appropriate location. Aim the machine at the hitting area or home plate.



Select the type of ball (baseball or softball) you are going to pitch and adjust the "GAP" accordingly (Consult the "GAP" selection).

Select the delivery or pitching angle by adjusting the pitching head elevation.

Before plugging the machine into the power source, be certain the speed control knob is turned to "**LOW**". Plug the machine into a surge protector and plug the surge protector into the power source.

Start the machine by setting the safety switch to "**RUN**", then turn the speed control knob clockwise to the desired setting. Allow adequate time for the wheel to reach the required RPM before inserting the first ball into the feed chute.

Throw the first pitch and adjust the location as required. To adjust the inside/outside location simply move the pitching machine left or right on the tripod. To adjust the pitching height, loosen the Pitching Head Elevation and reposition the head as required.

After setting the speed and location, pitch at least 10 balls BEFORE allowing the batter to step into the batter's box. The hitter should watch these 10 test pitches to become accustomed to the overall speed and angle of the delivery.

Throwing Groundballs and Fly balls:

To throw fly balls, tilt the pitching head back and lock in place. Set the speed as needed to achieve desired distance.

To throw groundballs, tilt the pitching head forward. Set the speed as needed.

* To turn the machine off, turn the speed control knob counter-clockwise to "**LOW**" then set the safety switch to "**STOP**".

GAP SELECTION

Gap Selection
The term “GAP” refers to the space between the pitching wheel and the pad above the wheel. The **Combo-Pitch Pitching Machine** is designed to throw both dimpled baseballs and dimpled softballs. Different balls require different “GAPS”.

You may use your **Combo-Pitch Pitching Machine** to only pitch dimpled baseballs or dimpled softballs. It is not necessary to change the GAP very often unless you plan to use different sizes and types of balls.

To Change the Gap
Turn the machine off and unplug the cord

Note that there are two slits on the pitching machine where the pad attaches to the body of the pitching machine.

To change the Gap for baseballs, lower the pad all the way to the bottom and tighten the bolts in place

To change the Gap for 12” softballs, raise the pad to the top and tighten the bolts in place

To change the Gap for 11” softballs, WITH THE PITCHING MACHINE OFF AND UNPLUGGED, place the softball between the top of the wheel and the pad and push down on the pad so that the ball is firm and tighten the bolts.





CHANGING BASEBALL/SOFTBALL FEED

The **Combo-Pitch Pitching Machine** comes with the baseball feed already assembled. To change the feed for softballs:

1. Use a Phillips screwdriver or the #10 wrench to remove all four (4) screws from the corners of the ball feed.

2. Remove the baseball feed chute, and replace with the softball feed chute.

3. Replace all screws. **** Do not overtighten the screws ****



SAFETY INSTRUCTIONS

- Never use the **Combo-Pitch Pitching Machine** in or near water or in a high moisture environment.
- Never place any part of your body on or near any part of the pitching wheel or in front of the machine while it is in operation and/or connected to a power source.
- Keep hands away from all moving parts.
- Batter should always wear protective head gear, preferably with a face guard.
- Turn the machine off and wait for the pitching wheel to stop rotating before changing the tilt angle of the pitching head. Do not attempt to manually stop the wheel from rotating, even after turning the power off.
- Place a protective pitcher screen in front of the machine to protect both the machine and the operator. Cimarron pitcher screens are sold separately.
- Before each use, check the pitching wheel for tightness. Tighten with an Allen wrench.
- Before connecting the **Combo-Pitch Pitching Machine** to a power source, make certain the speed control is set to "**LOW**".

WARNING!

This machine is not guaranteed to be 100% accurate. Occasional errant pitches may occur due to balls in poor condition, moisture, careless or negligent use, improper maintenance, or other factors.

It is important to make certain that all safety precautions are taken and to instruct all participants on proper operating procedures before allowing them to operate the machine. **It is the owner's responsibility to make certain the machine is in good working order, properly maintained, appropriately adjusted, and all safety measures are followed before and during each use.**

CAUTION

Using excessive speeds for amusement can be very dangerous, can lead to serious injury or even death, and is not recommended. For your safety, we ask that you use the **Combo-Pitch Pitching Machine** only for its intended purpose. Select speeds that are equal to the batter's level of ability.

We recommend that high speeds not be used when pitching from Little League or softball distance.

NOTE: A 60 mph pitch from 40 feet is equivalent to a 90 mph pitch from 60 feet. To calculate the equivalent of any pitch from 40 feet, multiply the actual speed by 1.5

Power Sources, Extension Cords, & Speeds

Power Sources:

Your **Combo-Pitch Pitching Machine** operates on 110/120 volt AC electricity (60Hz). You may plug your machine directly into a standard 110v household outlet or use an extension cord as noted below.

Extension Cords:

If you require an extension cord, it is important that you select one with an adequate wire gauge. An inadequate cord will cause overheating, poor performance, and premature motor or electronic circuit board burnout.

Adequate wire gauge size depends on the length of the cord. The longer the cord, the thicker the wire gauge needed. Wire gauges come in even numbers (8, 10, 12, 14, 16, etc.). The lower the number, the thicker the wire. For example, an 8-gauge cord is thicker than a 16-gauge cord.

When selecting an extension cord, please follow these basic guidelines:

CORD LENGTH	RECOMMENDED GAUGE
25 Feet	16 Gauge
50 Feet	14 Gauge
100 Feet	12 Gauge
150 Feet	10 Gauge
200 Feet	8 Gauge

Operating Speeds:

Your **Combo-Pitch Pitching Machine** has a variable speed control allowing your **Combo-Pitch Pitching Machine** to pitch balls at speeds from about 15mph to 60mph. Make sure the speed control is turned to "**LOW**" when turning the machine on. Slowly increase the speed until you arrive at the pitching machine speed that you desire.

MAINTENANCE

Your **Combo-Pitch Pitching Machine** requires periodic maintenance. Please follow these basic instructions to ensure proper performance of your machine.

- Check all nuts and bolts for tightness before each use
- There is a single point where the pitching head pivots vertically. The locking handle at this point should be tight enough to keep the pitching head in the proper elevation without rotation during use. DO NOT over tighten.
- When not in use, store the **Combo-Pitch Pitching Machine** in a clean, dry location. If you choose to leave your machine outside, make sure it is covered and kept dry. Cimarron Sports does not recommend storing your machine outside. Moisture will ruin the electronic circuitry of the machine and void the warranty. Additionally, constant exposure to direct sunlight will shorten the lifespan of the pitching wheel.
- Keep the pitching wheel clean, dry, and free of debris. Residue from balls does not need to be removed. If you need to clean the pitching wheel, rubbing alcohol and a coarse rag work very well. **DO NOT CLEAN THE WHEEL WITH THE MACHINE PLUGGED IN AND/OR RUNNING!**

NOTE: After throwing several thousand pitches, you will notice a groove forming on the pitching wheel and that material from the wheel has collected on other parts of the machine. This is normal. Simply remove the material and debris that has collected on the machine.

Use care when transporting your **Combo-Pitch Pitching Machine**. Avoid the following:

- Allowing the pitching machine wheel to come in contact with the ground.
- Dropping the machine
- Laying the machine down with the speed adjustment knob facing downward.
- Bending any metal parts.
- Stepping or pulling on the electrical cord.

Occasionally, you may need to tighten the pitching wheel retaining bolt. The pitching wheel on the **Combo-Pitch Pitching Machine** is secured to the motor shaft by a retaining bolt located in the center of the wheel. This retaining bolt **MUST BE** kept tight.

WARRANTY

This warranty is for the **Cimarron Combo-Pitch Pitching Machine** pitching machine.

The warranty period covers the first three (3) months of use from the date of purchase for commercial use and one (1) year for residential use from the date of purchase.

During this period, Cimarron Sports warrants that it will, at its own option, repair, replace, or adjust, free of charge, any part that Cimarron Sports finds to be defective in materials and/or workmanship when used within the conditions of this warranty. All shipping costs related to returning products to Cimarron Sports will be the responsibility of the customer.

Subject Conditions & What Your Warranty Does Not Cover:

- The defect is a consequence of the customer's failure to properly maintain, or use the **Combo-Pitch Pitching Machine** in accordance with good practice
- This warranty does not apply to conditions caused by abuse, neglect, improper maintenance, or misuse.
- Shipping damage not originating from original product shipment to customer
- Normal wear and tear
- Water damage.
- Use of improper balls
- Any damage resulting from acts of nature.
- Using leather or synthetic leather balls voids the warranty
- Damage to electronic circuit board or motor by using improper extension cords.

CUSTOMER SERVICE

Prior to returning a product to Cimarron Sports, you must do the following:

1. Call us at 888-816-6517
2. Have your proof of purchase (receipt, bill of sale, or invoice) ready
3. Explain the problem to the representative who answers the phone
4. If the representative determines that you should return your product, you will be provided with a return authorization number. This number should be written on the outside of the shipping carton when you return the product.
5. Return the product in question along with a brief description of the malfunction.
6. Please include the following information:
    - Your full name
    - Your address
    - Your phone number
    - Your e-mail address
    - A copy of your proof of purchase